

Access to the inner bins

Device version: every


VIDEO TUTORIAL

https://www.youtube.com/embed/M-l_PKStHko?ab_channel=WorldofBin-e

DESCRIPTION

If you want to get access to the inner bins and your device is equipped with the lock you will need a special key which was attached to the device when you received it. Simply open the front cover with the key.

Open the front cover by pulling it up. Inside you will find 4 inner bins, each of them is monitored with a fill level sensor so it is important to place them inside in a proper position. There is a limit switch which indicates where the bin should be placed. If the bin is standing crookedly, take it out and put it back again. To take the bin out of the casing you have to grab the hand grip and pull it a bit up and slowly take the bin out.



WE DO NOT RECOMMEND using plastic rubbish bags because they disturb the work of the fill level sensors and the device might communicate false fill levels.

When you finish replacing or emptying the inner bins just close the front cover and check if there is no error on the screen.

Revision #5

Created 2021-11-26 11:43:30 UTC by Armina

Updated 2021-11-26 13:42:59 UTC by Armina