

First launch

Device version: every 4.x.x

VIDEO TUTORIAL


https://www.youtube.com/embed/N1MoEtiifu4?ab_channel=WorldofBin-e

DESCRIPTION


After taking the device out of the box it is ready to be launched. First open the box which was placed in the first inner bin. Inside there is a power cable. The plug is placed on the back of the device in the bottom left corner. After you plug the cable to the device you can connect it to the power source. Next step is to press the switch on the bottom and then press the top button. The touch screen on the top cover should launch and display a progress bar, this process should take around 3-4 minutes.

During the launching the device will load the software, calibrate some inner components and check if inner bins are inside in the right position. If there are no notifications about an error on the touch screen, the device is almost ready to be used.

The device requires connection with the internet. If you are going to use a GSM modem which is placed inside, there is no action needed. The device will connect itself.



If you want to connect the device with WiFi you have to enter the menu by pressing the button in the right top corner and enter “Connection” settings . Enter the details required to connect and accept.



The interface is English by default, but if you want to change the language just enter the MENU >> SETTINGS >> LANGUAGE.

Revision #9

Created 2021-11-26 09:50:41 UTC by Admin

Updated 2021-11-26 13:41:53 UTC by Armina